




Mighty Carver Disassembly Instructions

Thank you for your purchase! Please use the guidelines below to disassemble your Mighty Carver in order to clean and store.

1. To release the **Bar/Blade Guide** from the Mighty Carver, gently pull the start handle (labeled "A" in the diagram below) and remove plastic cover.
2. To release the **Stainless Steel Blade** from the Mighty Carver, push the "gas cap" (labeled "B" in the diagram below) and remove metal blade.

***CAUTION:** blades are sharp and should be handled with extreme care.



Are you more of a visual learner? Scan the code for a how-to video to assemble/disassemble the Mighty Carver blade guide and blade.

If additional assistance is needed, please contact Mighty Carver at **407.915.7053** or **info@mightycarver.com**.

Any other questions? Visit: **mightycarver.com**